


**BEECHCRAFT
DUKE 60 SERIES
MAINTENANCE MANUAL**

DISTRIBUTION - MAINTENANCE PRACTICES

The functional diagrams on the following pages provide a detailed layout of the distribution system utilized by the various series of the Duke.


100-HOUR INSPECTION

Distribution Ducts - Check cabin hot and cold air outlet valves for condition, obstructions and proper operation; check heating and cooling ducts for condition and attachment.



**Pressurization Distribution System
Figure 201**

BEECHCRAFT
DUKE 60 SERIES
MAINTENANCE MANUAL



Air Conditioning Distribution System (P-3 thru P-246)
Figure 202